## QUICK FIX Acid Drain Cleaner w/ Odor Blanket

Form: Liquid	Other Uses	
<b>Color:</b> Clear water-white (upper layer) Brown (lower layer)	X-ray Room Drains	
Odor: Solvent/Acidic	Wastewater Treatment Systems	
<pre>pH: &lt;1.0 Solubility (in water):Complete (lower layer)   (in mineral spirits):Insoluble (upper layer)</pre>	Restaurant Drains	
VOC Content (% by weight): N/D	Paper Mill Drains	
Flash Point (ASTM D-7821):125°F	Nursing Home Drains	
<b>Specific Gravity:</b> 1.81 g/cm <sup>3</sup> (lower layer)	Hospital Drains	
Density: 15.10 lbs/gal	Textile Mill Drains	
Storage Stability (at 70°F):	· Textile Will Drains	
Ingredients         C.A.S. #           Sulfuric Acid         7664-93-9           Water         7732-18-5		

**DIRECTIONS:** Empty entire contents into drain and quickly cover opening with a deep container to shield against any splash back. Refasten cap tightly on empty bottle, wrap in several layers of paper, and discard in trash. Wait 15 minutes, then clear drain of acid by flushing with a large amount of cold water. Repeat treatment if necessary.

**ATTENTION:** Wear acid-resistant face shield, apron, and gloves. Product could react violently with some materials, causing gases and hot acid to spray back out of drain. Never use product in drains after, with, or before hot water, other drain openers, or other chemicals. Do not add water to acid. Do not pour into standing water or a completely stopped drain. Never use with plunger.

HMIS				NFPA
	Severe	4	Extreme	
Health3	Serious	3	High	Health3
Flammability2	Moderate	2	Moderate	Flammability2
Reactivity2	Slight	1	Slight	Reactivity2
Personal ProtectionX	Minimal	0	Insignificant	Special PrecautionsNone